#HA33970C HT 13(Spencer Gift) • Size: 3" x 7.75" Back



#HA33970C HT 13(Spencer Gift) • Size: 3" x 7.75" Front

#HA33970C HT 13(Spencer Gift) • Size: 3" x 7.75" Inside



THIS PRODUCT INCLUDES 3 "AA" BATTERIES FOR SHELF SALES DEMONSTRATION PURPOSES ONLY. MANUFACTURER MAKES NO GUARANTEE AS TO DEMONSTRATION BATTERY LIFE. IT IS POSSIBLE THAT THE BATTERIES INCLUDED WILL BECOME WEAK OR DISCHARGED IN THE STORE. THE CONSUMER SHOULD NOT FORGET TO PURCHASE REPLACEMENT BATTERIES.

TO REPLACE BATTERIES

- 1. Locate battery compartment on the back.
- 2. Turn off switch.
- 3. Unscrew battery compartment door with a screwdriver.
- 4. Replace with 3 "AA" size batteries observing the polarity drawing inside case.
- 5. Replace the cover and turn switch back to "ON" position.

Slide switch to "ON" position to activate the item by sound sensor, simply walk by to activate. Slide switch to "OFF" to activate the item by pressing

(This item is preset to "OFF" mode for store demonstration purpose).

PRECAUTION:



- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon zinc) or rechargeable (nickel - cadmium) batteries.
- Non rechargeable batteries are not to be recharged.
- Batteries should only be changed under adult supervision.
- Do not dispose of batteries in fire, batteries may explode or leak.
- Exhausted batteries are to be removed from the product.
- The supply terminals are not to be short-circuited.
- Do not use rechargeable batteries.
- Batteries are harmful if swallowed, so keep away from young children.
- Only batteries of the same or equivalent type as recommended are to be used.
- Clean the battery contacts and also those of the device prior to battery
- Remove battery if product left unused for long time

Please retain this information for future reference.

#HA33970C HT 13(Spencer Gift) • Size: 3" x 7.75" Inside

FCC Warning Tag (Spencer Gift) • Size: 2" x 2.5"

This device complies with the part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed

0 and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 Increase the separation between the
- equipment and receiver. Connect the equipment into an outlet on
- a circuit different from that to which the receiver is connected.
- Consult the dealer or experienced radio/

TV technician for help.

Back Front