



INSTRUCTIONS

⚠ ATTENTION:
**DISCONNECT POWER
BEFORE ANY SERVICE.**

CAUTION:

- This is not a toy. Use only with adult supervision.
- Do not operate without liquid in The Bubble Fogger™.
- Do not tip over. Set on a level surface.
- Operate in open, dry, and well-ventilated area only.
- Do not leave unattended.
- Unplug when not in use.
- Do not use around pets.
- Unit is hot during normal operation.
- Bubble or fog solution may leave a residue. Clean up spills or accumulation on floor immediately.
- Do not immerse in water. Wipe clean with a damp cloth after cool down.
- Do not remove the cover, there are no serviceable parts inside.
- Disconnect power before changing fuse.
- During storage, be sure all liquids are removed.
- Fog mist may activate some fire alarms, please use care when operating.
- Household type.

IMPORTANT: PLEASE READ ALL THE INSTRUCTIONS CAREFULLY BEFORE USING THIS PRODUCT

SPECIFICATIONS:

- **Input power:** 120 volts, 60 Hz, 200 W.
- **Fuse Type:** 125 volts, 2 Amps. Quick acting.
- **Tank Capacity:** 0.21 Quart (198.73 ml) for fogger juice
0.16 Quart (151.40 ml) for Bubble juice
- **Warm-up Time:** Approximately 2-5 minutes.

WARNING: This product is recommended for indoor use only. To reduce the risk of fire or shock hazard, do not expose this product to rain, moisture or dust.

CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT OPEN THE COVER. NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED TECHNICIAN.

CAUTION: To provide continued protection against risk of electric shock, connect to properly-grounded outlets only. The Bubble Fogger™ is equipped with a three-wire grounding type plug. This plug will only fit into a grounding type AC power outlet. This is a safety feature. If you are unable to insert the plug into your AC power outlet, contact your electrician to replace your outlet. Do not defeat the purpose of the grounding-type plug.

CAUTION:


- **Hot surface.** To avoid contact, always use the handles to carry The Bubble Fogger™.
- Vapor from The Bubble Fogger™ may be irritating to some persons with allergic sensitivity.
- Do not expose at close range to known asthmatics.
- Use in a well-ventilated area.



INSTRUCTIONS

Congratulations! You're the proud owner of The Bubble Fogger™ from Gemmy. Please read over the directions carefully before using your Bubble Fogger™.

GENERAL INSTRUCTIONS



1. Always place this product on a flat, stable, heat-resistant surface, keeping the unit level.
2. Unscrew the reservoir tank lid on back of machine and fill with Fog Solution. Close the reservoir tank lid tightly. Always make sure there is enough fluid in the tank before using The Bubble Fogger™.
3. Fill bubble juice into bubble reservoir. Always make sure there is enough liquid in the tank before use.
4. Plug the A/C power cord into a standard A/C grounded wall outlet.
5. Turn the ON/OFF switch located on back of The Bubble Fogger™ to the "ON" position.
6. It will take approximately 2 to 5 minutes for The Bubble Fogger™ to warm up. When fully heated, the orange indicator light beside bubble reservoir will light up indicating that the machine is ready.
7. Turn LARGE-STANDBY-SMALL switch to "SMALL" for small bubbles and to "LARGE" for big bubbles.
8. When not in use, please turn the ON/OFF switch on the back of The Bubble Fogger™ to the "OFF" position and unplug the A/C power cord from the wall outlet.

USER SERVICING INSTRUCTIONS

Fuse Replacement

⚠ WARNING: Risk of Fire: To reduce the risk of fire, replace only with same size and type of fuse.

1. Grasp plug and remove from the receptacle or other outlet device. Do not unplug by pulling on cord.
2. Open fuse cover with phillips screwdriver. Remove fuse carefully.
3. Replace fuse only with 2.0 Amps, 125 Volts fuse.
4. Close fuse cover.

SAFETY INFORMATION

1. Not recommended for any other use.
2. For adult use only. Keep out of reach of children and pets. When children or pets are present, close adult supervision is necessary.
3. Always operate The Bubble Fogger™ in an open, well-ventilated area.
4. Keep the nozzle 20" clear of contact with anything while in use.
5. Allow at least 8" free air space around the sides and top of the unit to allow for adequate ventilation. Never cover or block air vents.
6. To reduce the risk of fire or electric shock, do not expose the product to rain, moisture or dust. If water or dust gets into the housing, unplug the unit immediately and contact a qualified service technician.
7. Do not leave unattended while in use. Always unplug the unit from the electrical outlet when unattended.
8. Do not allow the power cord to hang or rest in a way that it can be tripped over or pulled.
9. Use with a 3 prong, grounded electrical outlet only.
10. Do not operate within 3 feet of electrical devices such as refrigerators, televisions, microwaves or heaters.
11. Activating the pump without fluid can cause damage to the pump and heater.



INSTRUCTIONS

QUICK OPERATING TIPS

1. Always use The Bubble Fogger™ with adult supervision.
2. Never drink the fog solution and bubble solution.
3. **DO NOT** expose fog spray and bubbles to known asthmatics or allergenic sensitive people.
4. The Bubble Fogger™ is not water-proof or splash-proof. When outdoors, use under a covered area.
5. When indoors, use in well-ventilated areas to avoid setting off smoke detectors.
6. Use with caution. It is normal for residue to build up under the nozzle and drop to the floor. This can cause a slick area and create slipping hazard.
7. The Bubble Fogger™ nozzle at least 2 feet away from any person or objects. Small bursts will spray out before the nozzle and create slipping hazard.
8. Do not move the machine while in operation. Allow the unit to cool before handling or servicing.
9. Always place The Bubble Fogger™ on a flat, stable surface.

WARNING

Remove all plastic fasteners and tags. These are part of the packaging and should be discarded.

TROUBLE SHOOTING CHECKLIST

If your Bubble Fogger™ is not working, the problem may be:

1. The power source is disabled or the cord may be unplugged .
2. There is not enough fog solution or bubble solution in the reservoir tank.

FREQUENTLY ASKED QUESTIONS (FAQ's)

1. Is artificial fog safe to breathe?

Most Bubble Foggers use fog solution made of a combination of water and a chemical called glycol which has been found to be safe and is not considered hazardous to humans. Bubble Fogger™ and fog solution can generally be used without problems. However, some people do complain of respiratory problems or throat irritation when exposed to theatrical fog. Because the fog can be irritating or drying, extended periods exposure to the fog should be minimized.

- If the Bubble Fogger™ is used indoors you should make sure the room has adequate ventilation.
- It is a good idea not to breathe the fog for extended periods of time.
- **DO NOT** expose the fog at close range to know asthmatics or allergenic sensitive people.

2. Can food coloring or scented fluids be added to the fog solution and bubble solution?

No. Never add materials of any kind (i.e. oil, gas, perfume, food coloring) to the solution.

3. Can I make my own fog solution and bubble solution?

No. We highly recommend against trying to make your own fog solution and bubble solution. The chemical content of Gemmy's solution are designed around the specifications of The Bubble Fogger™ by Gemmy. A home made fog solution and bubble solution will not be safe, hazard-free and as efficient as a commercial version. Only similar water-based fog and bubble liquid is recommended.

4. What do I do if my Bubble Fogger™ stops working?

The Bubble Fogger™ does not have serviceable parts inside. Do not open



FREQUENTLY ASKED QUESTIONS (FAQ'S)

INSTRUCTIONS

the cover. Replace the fuse only with 2.0 Amps, 125 Volts.

- **Don't Touch! Bubble Foggers™ get hot.**

Always use the attached hanging bracket as a handle when carrying the Bubble Fogger™. Allow the Bubble Fogger™ to cool down before moving or hanging. Make sure you place the Bubble Fogger™ in a place away from combustible materials, i.e. curtains, leaves, paper, etc.

- **Check the level of fog and bubble solution.**

Be sure to periodically check the level of fog solution and bubble solution. Fill The Bubble Fogger™ tank up and then check it about every hour.

5. Is fog or bubble blowing directly onto food or pets harmful?

It is not recommended that the fog and bubble from The Bubble Fogger™ be blown directly onto food or pets. The fog spray may leave a light residue on surfaces. Again, use in well-ventilated areas.

6. How much solution will The Bubble Fogger™ use?

Generally one quart of bubble solution and fog solution can work five hours. Variables such as the small and large bubble settings will affect how long The Bubble Fogger™ is able to produce bubbles.

7. Can I use water in my Bubble Fogger™?

No. Water may cause permanent damage to your Bubble Fogger™.

8. Why is there bubble solution residue in the bubble tank at the time of purchase?

While the manufacturer takes great steps to remove all bubble solution after the quality control test at the factory, there is a possibility of some residue remaining after. This does not affect the operation of your Bubble Fogger™.

9. I started my Bubble Fogger and no fog was inside the bubbles. Why is this?

During the initial warm up time, the fog may or may not appear inside the bubbles. The problem should resolve itself after a few minutes of operation.

10. Why is there fog emission and no bubbles?

This is normal, as the bubble wand is set on a timer. After the fog bubbles stop and before the next activation – there will be some fog emission and no bubbles.

THESE INSTRUCTIONS ARE FOR ITEM:

20931,24564,22739,72025



INSTRUCTIONS

WARNING

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



Visit WWW.GEMMY.COM for more information.

©2010 GEMMY INDUSTRIES CORP.

COPPELL, TX 75019 U.S.A.

(972) 961-7000

MADE IN CHINA / PRINTED IN CHINA